

Shed Assembly

Tools. Spirit level, hammer, pozi screwdriver (preferably battery), handsaw, silicone gun, step ladder. Kraft knife. Two people required.

Alpine / GarageLodge



84.Photo

Base preparation. A flat level base must be prepared on which to erect your building at least the same size or bigger. Use either flag stones, concrete or gravel.

Check for level using a spirit level in several positions.



85.Photo

Position the floor check for level again.



86.Photo


Position one side and the plain gable together on the edge of the floor.

Fasten together using 3 screws 63mm x10g



87.Photo

Fasten the remaining sides in the same manner.



88.Photo

Fasten the sides to the floor using screws 63mm x10g. Make sure the screws are positioned so they screw into the floor framing.



89.Photo,90.Photo

Position the upper floor onto the horizontal support frame with the cut outs in the correct position.




91.Photo

Using a 63mm x 10g screw fasten the floor to the centre upright frame of the adjoining wall.




92.Photo,93.Photo

Fasten the floor beams to the relevant framing as shown using 63mm x 10g screws in the pre drilled holes.



94.Photo,95.Photo, 96.Photo,97.Photo, 98.Photo

Fasten the floor beams to the relevant framing as shown using 63mmx10g screws in the pre drilled holes.





99.Photo

Fasten the vertical support using 63mmx10g screws to the centre upright frame of the wall.



100.Photo

Lower fence, fasten to the vertical frame of the plain gable with a 63mm x10g screw thro the pre drilled hole.



101.Photo,102.Photo
Lower fence. Using two 63mm x10g screws secure fence to floor beams.




103.Photo

Screw through pre drilled hole in upper floor into vertical rail of lower fence with 90mmx10g screw.



104.Photo,105.Photo,106.Photo

Place the first roof panel to rest in position on the plain gable and door gable. Allow the roof panel to overhang the plain gable by 75mm.



Now repeat the procedure with the second roof panel. This will leave the correct overhang at the front.



107.Photo,108.Photo
Fasten together the top roof beams with a 63mmx10g screw in the centre of the shed and on the overhang.



109.Photo,110.Photo
Nail through the roof boards into the gable frame with 50mm nails at 100mm spaces. Nail through the boards using 50mm nails into the vertical frame on the sides



111.Photo,112.Photo
Place length of felt on roof with sand to top. Equal overhang at each end and sufficient to cover the frame at the lower end of the roof panel. Now using eight 13mm clout head nails fasten the top edge of the felt.



113.Photo
Fasten the lower edge of the felt at 75mm spaces with 13mm clout head nails. Repeat the operation on the second roof panel.



114.Photo
With equal overlaps position and nail at 75mm spaces the third length of felt.



115.Photo
Position and nail the four corner strips using four 50mm nails in each strip.



I 16.Photo, I 17.Photo, I 18.Photo.

Position and secure veranda rails using five 63mmx10g screws on each rail.




I 19.Photo

Fold over the ends of the roof felt and cover with the appropriate fascia board. Nail through the board into the framing using six 50mm nails on each board.




I 20.Photo

Fix the two finials with two 25mm nails.



I 22.Photo

Remove the protective film from the polycarbonate pane and place in position.



I 23.Photo

Using two 25mm nails fit the beeding over the pane. Repeat on the second pane.



I 24.Photo, I 25.Photo

Secure top fence using 63mm x10g screws through pre drilled holes. The vertical end rail fastens to the roof beam





I 26.Photo

Position the ladder by lining up the hole in the side rail with the vertical frame in the plain gable and secure with a 63mm x 10g screw.



I 27.Photo

Now fasten the 50x50mm steel bracket the ladder and the floor using 25mm x 6g screws.



I 28.Photo

Using a 63mm x 10g screw fasten the top of the ladder to the vertical frame in the plain gable.



I 29.Photo

Using a 63mm x 10g screw fasten the top of the ladder to the vertical frame in the fence.



I 30.Photo

Position the shutters over the pre drilled holes in the door gable and fasten using four 25mm x 6g screws on each shutter.



I 31.Photo

Fasten the door handle using two 25mm x 6g screws into the frame of the door.



I 32.Photo

It is extremely important to thoroughly check the whole building to ensure no nails or screws are left protruding (sharp points) any that are found must be rectified immediately.

A top coat of child friendly preservative must be applied to the playden as soon as possible after assembly to protect from the elements.

Your playden is now complete.