

## Shed Assembly

Tools. Spirit level, hammer, pozi screwdriver (preferably battery), handsaw, silicone gun, step ladder. Kraft knife. Two people required.

### Apex Rustic, Unistore, Apex Wharfedale, Apex Wensleydale, Apex Garsdale, Apex Security, Apex Swaledale, Cabin Swaledale, Warfedale Cabin.



#### 38.Photo

Base preparation. A flat level base must be prepared on which to erect your building at least the same size or bigger. Use either flag stones, concrete or gravel.

Check for level using a spirit level in several positions.



#### 39.Photo

Position the floor check for level again.



#### 40. Photo

Alternatively use bearers set out equally on the prepared base. Use spirit level on each bearer and at right angles to make sure they are all exactly the same height.



#### 41.Photo

Position the floor check for level again.



#### 42.Photo

Position one side and the plain gable together on the edge of the floor.



**43.Photo**

Fasten together using 3 screws 63mmx10g



**44.Photo**

Fasten the remaining sides in the same manner.



**45.Photo**

Fasten the sides to the floor using screws 63mmx10g. Make sure the screws are positioned so they screw into the floor framing.




**46.Photo,47.Photo**

Place the first roof panel to rest in position on the plain gable and door gable. Repeat with second panel.



**48.Photo,49.Photo**

Nail through the roof boards into the gable frame with 50mm nails at 100mm spaces. Nail through the boards using 50mm nails into the vertical frame on the sides




**50.Photo**

Place length of felt on roof with sand to top. Equal overhang at each end and sufficient to cover the frame at the lower end of the roof panel. Now using eight 13mm clout head nails fasten the top edge of the felt.




**51.Photo**

Fasten the lower edge of the felt at 75mm spaces with 13mm clout head nails . Repeat the operation on the second roof panel.



**52.Photo**

Fasten together the top roof beams with one 63mmx10g screws in the centre of the shed.



**53.Photo**

With equal overlaps position and nail at 75mm spaces the third length of felt.



**54.Photo**

Fold over the ends of the roof felt and cover with the appropriate fascia board. Nail through the board into the framing using six 50mm nails on each board.



**55.Photo**

Fix the two finials with two 25mm nails



**56.Photo**

Position and nail the four corner strips using four 50mm nails in each strip.



**57.Photo**

Remove the protective film from the polycarbonate pane and place in position.



**58.Photo**

Using two 25mm nails fit the beeding over the pane. Repeat on the second pane.



**59.Photo**

Using two 25mm nails secure the centre strip making sure to miss the panes with the nails.



**60.Photo**

Seal round the edges with a bead of silicone.



**61.Photo**

If you have not requested a top coat of preservative, this must be done as soon as possible to protect the timber from the elements. Be sure to use a solvent based preservative.

Your shed is now complete.