

## Shed Assembly

Tools. Spirit level, hammer, pozi screwdriver (preferably battery), handsaw, silicone gun, step ladder. Kraft knife. Two people required.

### Den, Daffodil, Gingerbread, Bluebell



#### 62.Photo

Base preparation. A flat level base must be prepared on which to erect your building at least the same size or bigger. Use either flag stones, concrete or gravel.

Check for level using a spirit level in several positions.



#### 63.Photo

Position the floor check for level again.



#### 64.Photo

Position one side and the plain gable together on the edge of the floor.

Fasten together using 3 screws 63mmx10g



#### 65.Photo

Fasten the remaining sides in the same manner.



#### 66.Photo

Fasten the sides to the floor using screws 63mmx10g. Make sure the screws are positioned so they screw into the floor framing.



**67.Photo**

Place the first roof panel to rest in position on the plain gable and door gable.



**68.photo,69.Photo**

Fasten together the top roof beams with a 63mmx10g screw in the centre of the shed and on the overhang.



**70.Photo,71.photo**

Nail through the roof boards into the gable frame with 50mm nails at 100mm spaces. Nail through the boards using 50mm nails into the vertical frame on the sides



**72.Photo**

Place length of felt on roof with sand to top.Equal overhang at each end and sufficient to cover the frame at the lower end of the roof panel. Now using eight 13mm clout head nails fasten the top edge of the felt.



**73.Photo**

Fasten the lower edge of the felt at 75mm spaces with 13mm clout head nails . Repeat the operation on the second roof panel.



**74.Photo**

With equal overlaps position and nail at 75mm spaces the third length of felt.




**75.Photo**

With equal overlaps position and nail at 75mm spaces the third length of felt.



**76.Photo,77.Photo**

Remove the protective film from the polycarbonate pane and place in position.



**78.Photo**

Using two 25mm nails fit the beeding over the pane. Repeat on the second pane.




**79.Photo**

Fold over the ends of the roof felt and cover with the appropriate fascia board. Nail through the board into the framing using four 50mm nails on each board.




**80.Photo**

Fix the two finials with two 25mm nails.



**81.Photo**

Fasten the handle to the door using 25mmx8g screws.



### **82.Photo**

Position the window boxes over the pre drilled holes and secure with eight 32mmx8g screws.



### **83.Photo**

It is extremely important to thoroughly check the whole building to ensure no nails or screws are left protruding (sharp points) any that are found must be rectified immediately.

A top coat of child friendly preservative must be applied to the playden as soon as possible after assembly to protect from the elements. Your playden is now complete.